## S & S MODELS 28(1)(1) CROMWELL ARV INSTRUCTIONS

THE CROMWELL AND CENTAUR TANKS WERE CONVERTED INTO RECOVERY VEHICLES DURING THE LATER STAGES OF WW2 AND SAW EXTENSIVE SERVICE IN THE NWE CAMPAIGN.

THE TURRET WAS REMOVED AND PLATED OVER AND VARIOUS RECOVERY EQUIPMENT WAS PLACED AROUND THE HULL.

OTHER STOWAGE WAS ALSO ADDED BY CREWS TO MAKE THE JOB EASIER LIKE MORE ROPES AND PULLEY BLOCKS.

THE PARTS ARE DESIGNED FOR THE WARLORD OR ITALERI CROMWELL BUT IT SHOULD FIT OTHER 1/56TH MODELS.





## **S&S MODELS**

22 BRIAR CLOSE BURNHAM ON SEA SOMERSET U.K. TA8 1HU

www.sandsmodels.com

## **SAFETY**

DO EAT OR CHEW ANY OF THIS PRODUCT AS IT MAY CONTAIN LEAD. ALWAYS WASH HANDS AFTER HANDLING ANY UNPAINTED PARTS.

**UNSUITABLE FOR CHILDREN**